

LOW VOLTAGE LIGHTING : INSTALLATION INSTRUCTIONS

- 1** REMOVE EGG CRATE SOFFIT PANEL.
- 2** LIGHT FIXTURE IS INSTALLED ON THE FRONT DOOR SIDE OF DISPLAY CASE, ABOVE THE HORIZONTAL FRAME, ON THE MASONITE PANEL. POSITION FIXTURE SO THAT MAXIMUM AMOUNT OF LIGHT PENETRATES THE EGG CRATE. SEE DRAWING.
- 3** USE SILICONE TO ADHERE FIXTURE TO MASONITE PANEL.
- 4** ATTACH TRANSFORMER BOX TO TOP PANEL INSIDE SOFFIT AREA. MAKE SURE TO LEAVE ACCESS TO BOX FOR FUTURE SERVICE.
- 5** DRILL HOLE FOR CORD through BACK OR TOP PANEL AS NEEDED.
- 6** REPLACE EGG CRATE PANEL.

PLEASE NOTE: THESE INSTRUCTIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.



Peter Pepper Products, Inc. • T: 310.639.0390 x 7 • F: 310.639.6013 • E: customerservice@peterpepper.com